

QUAD

Mounting guide





Important warnings

- X Avoid exposing the camera to shocks, high pressure or temperatures above 60°C.
- X Avoid placing the camera near fans, ventilation or other noise sources. This will degrade audio performance.
- X Avoid scratching or leaving fingerprints on the lens cover, this degrades image quality. If possible, keep the protective plastic on the dome cover during installation.
- **X Do not** clean the camera with harsh detergents, gasoline or chemicals such as acetone.
- X Do not try to repair the unit yourself. Refer all servicing of the camera to Ava or contact a reseller.






Safety instructions


- ! Disconnect power from the unit when performing a maintenance task.
- ! The power supply should bear the UL listed and LPS marks.
- ! Requires PoE+ power connection to operate with IR.
- ! This product should be supplied by a Power over Ethernet Power Sourcing Equipment (PSE) compliant to IEEE 802.3at Type 2 (PoE+).
- ! The camera should be connected only to PoE networks without routing to the outside plant. The PoE PSE must be properly grounded.
- ! Please contact AVA's certified dealers (or distributor) for power adapters.
- ! For the grounding wire use a green/yellow wire (min. 18AWG), a knurled washer and min. 3.5mm screw.

Overview



Top view Outer view








Quad camera IR light cover Alignment sticker Screws and anchors T10 security L-key

Overview



Inner view




Preparing to mount the camera



For all install options

2 1 3



Preparing to mount the camera





4

Option A - Using the ceiling mount



A1






Option B - Using the in-ceiling mount



B1






If needed, add hanging rods to strengthen the ceiling structure. Weight of camera: 2.7 Kg Weight of Recessed kit: 1.1 Kg

Option B - Using the in-ceiling mount




B2

Assemble the bracket stand to the bracket rod, adjust the width so the stands are resting on the secondary keels. Secure the position by the two flathead screws.



B3

Remove the assembly from the ceiling and assemble the adapter plate to the bracket rod. Use nuts, washers and lock washers as shown, tighten the nut towards the adapter plate and make sure the two nuts close to the bracket rod are loose.



Option B - Using the in-ceiling mount




B4


Put the bracket assembly in the correct position in the ceiling and install the tile.

Assemble the camera top mounting plate to the adapter plate, adjust the position so the camera will be flush to the ceiling and the release button can be pressed.

B5

Fasten the remaining two nuts to secure position of the rod.







Option C - Using the pendant mount



C1

Use the alignment sticker and drill four holes. Fit the pendant head and mount it with the screws.





Install the pendant pipe and secure with the upper hex screw, install the mounting adapter and secure it with the lower hex screw.




Install the top mounting plate.

Note the front indicators indicate the default front side of the camera. Install the mounting plate with the orientation you prefer.







Required:



ACQ-PEN-HEA Pendant head ACQ-PEN-PIP Pendant pipe 40cm ACQ-MNT-ADA Mounting adapter

Option D - Using the wall mount



D1


Attach the alignment sticker to the wall. Drill 4 holes for screws and 1 hole for routing cable.


D2

Leave one washer on each threaded pole. Connect the Ethernet cable and use foam tapes or seal foam to ensure the back-end connection is waterproof.

D3

Route the cable along the routing guide poles to form drip loop.








Option D - Using the wall mount




D4 D5


Fasten bracket using nuts, washers and lock washers.





Secure the top mounting plate.





Option E - Using the pole or corner mount



E1


Install the pole bracket to the pole wrapping the metal bands around the pole. Or install the corner bracket to the corner using correct type of screws.


E2


Install the wall mount bracket to the pole or corner bracket as described on the previous page. Align the top mounting plate with the center of the wall mount bracket.


E3

Secure the top mounting plate.













ACQ-WAL-MNT Wall mount bracket ACQ-POL-MNT Pole bracket or ACQ-CRN-MNT Corner bracket


Completing the camera installation



1 2 3







Completing the camera installation




4


5

Adjust the image orientation in Ava Aware.


























Mind the electrostatic damage by avoiding contact with exposed circuitry.



Completing the camera installation



7 8 9

